

## Pg.4 Construction 2

Screw the 2 liter bottle firmly into the base.

Carefully slide the top collar over the top edge of the bottle, using the slots provided.

Connect the airline tube to the inlet in the base, and run the tubing up and through the channel provided in the top ring. This must be connected to avoid back siphoning.

Then, attach the airline to your air pump, with a valve adjusted to allow just enough air to keep all cysts in motion.

Fill the upturned 2 liter bottle to the magic marker line with water from your tap.

